


Remote Guide




NOTE:


Memory Position: Adjust head and/or foot section(s) to desired positions. Press and hold M button until the back-light on remote flashes. Release button and wait for flash to stop. Button has now been programmed. Repeat process if new preset position is desired.

Your base comes with a ready-to-use, factory paired remote. Pairing instructions are for replacement remotes or trouble shooting purposes.

PAIRING REMOTE TO BASE




Double click the PAIR button on the control box (light will turn blue during the pairing process).



Simultaneously press and hold the HEAD UP and HEAD DOWN buttons on remote until the remote back lights blink, and the control box light turns to green, then release remote buttons.

SYNCING 2 BASES TO ACT AS ONE




With both bases in FLAT position, connect each base to the other by inserting SYNC CABLE into each control box slot labeled sync.

NOTE: If using 3-in-1 legs, BOTH bases need to be converted to the same 3 in 1 leg configuration to maintain consistent deck height

If SYNCING 2 TXL bases together, follow these instructions.


Guide de télécommande




NOTA :

La base est accompagnée d'une télécommande, jumelée par défaut, prête à utiliser. Les instructions pour le jumelage sont fournies pour les télécommandes de rechange ou à des fins de dépannage.

JUMELAGE DE LA TÉLÉCOMMANDE AVEC LA BASE




Double-cliquez sur le bouton PAIR du boîtier de commande (le témoin lumineux deviendra bleu pendant la procédure de jumelage).



Appuyez simultanément sur les boutons TÊTE RELEVÉE et TÊTE RABAISSÉE et maintenez jusqu'à ce que le rétroéclairage de la télécommande clignote et que le témoin lumineux du boîtier de commande devienne vert, puis relâchez les boutons.

JUMELAGE DE DEUX BASES ENSEMBLE



Une fois les deux bases en position À plat, jumelez les bases ensemble en insérant le CÂBLE DE SYNCHRONISATION dans la fente marquée SYNC de chaque boîtier de commande.

NOTA : Si vous utilisez les pattes 3-en-1, les DEUX bases doivent être converties au même mode 3-en-1 pour maintenir une hauteur de plateforme compatible.

Pour JUMELER deux bases Simple TG ensemble, suivez ces instructions.